


PALAZZANI



easyclean



1. X



2.



3. ✓

Come ben sappiamo gli articoli a contatto con l'acqua subiscono il fenomeno della formazione del calcare. Anche soffioni doccia e doccette non sono esenti da questa problematica. E' proprio sulle tette delle uscite acqua che, quando non asciugate accuratamente dopo ogni utilizzo, la formazione del calcare diventa ancor maggiore, aumentando sempre più fino ad andare a bloccare l'uscita omogenea dell'acqua, creando diversi ed importanti problemi, uscita non regolare dell'acqua e/o blocco completo dell'ugello di uscita (**foto 1**).

Se più ugelli vengono chiusi dal calcare, la contro pressione potrebbe causare la rottura della cartuccia interna al soffione o alla doccetta e quindi la rottura degli articoli stessi. E' necessario quindi pulire, quando si notano delle ostruzioni, gli ugelli durante l'utilizzo della doccetta o del soffione. La pulizia è molto semplice da eseguire, è sufficiente sfregare le uscite con le dita durante l'utilizzo, in modo che il calcare venga ammorbidito dall'acqua che fuoriesce (**foto 2**).

La tecnologia **Easy Clean** permette di rimuovere rapidamente i residui e i depositi di calcare presenti nell'acqua dalle docce e dai soffioni grazie agli ugelli flessibili in silicone. A quel punto la doccia tornerà completamente funzionale, evitando malfunzionamenti e rotture (**foto 3**).

NB: Operazione da effettuare durante l'utilizzo di acqua per evitare rotture e malfunzionamento.

As we know the articles in contact with water are subject to the phenomenon of limestone formation. Even head shower are not exempt from this problem. It is right on the water outlet tapers that, when not carefully dried after each use, the formation of limestone becomes even greater, increasing more and more, until going to block the homogeneous water output, creating different and important problems, exit not adjust the water and/or complete block of the outlet nozzle (**photo 1**).

If more nozzles are closed by limestone, the counter pressure could cause the internal cartridge to break at the shower head, or the hand shower and therefore the breaking of the articles themselves.

Is therefore necessary clean the nozzles when obstructing are notice during use of hand shower or head shower. The cleaning is very simple to perform, just rub the exits with your fingers during use, so that the limescale is softened by the water that comes out (**photo 2**). The **Easy Clean**, technology allows to quick remove residual or limestone deposits in the water from showers and overhead showers thanks to the flexible silicone nozzles.

At that point the shower will return fully functional, avoiding malfunctions and breakages (**photo 3**).

NB: Operation to be carried out when using water to prevent the breakage and malfunction.

PALAZZANI.EU SRL: Sede legale: Via Caselle, 22 - 25125 Brescia • Produzione e magazzini: Via Mario Anelli,

75/77 - 26020 Casalmorano (CR)

tel +39.0374.74141 - fax +39.0374.74524 • info@palazzani.eu - www.palazzani.eu